



Audi

MELGES²⁰

How trim the Anti-hiking lines

C.6.1. (h) The backsider anti hiking strap shall be adjusted so that when pushing down hard on the center of the pad it shall not touch the deck at any location. The backsider anti hiking pad shall be shockcorded aft to pull out any slack so that the pad is taught between stanchions. The port and starboard backsider anti hiking pad shall each be tied off at their respective port and starboard aft stanchions using a minimum of 3mm high strength line making three complete loops before tying off.

LEGAL



ILLEGAL



.....using a minimum of 3mm high strength line making three complete loops before tying off.

LEGAL



LEGAL



ILLEGAL



PLEASE REMEMBER

:

THE RULES OF THE AUDI MELGES20 CLASS ARE CLOSED CLASS RULES :
WHERE IF IT DOES NOT SPECIFICALLY SAY THAT YOU MAY,
THEN YOU SHALL NOT.

For any doubt or question please Contact Egidio Babbi at: info@egidiobabbi.it